

Step 1: Install Privacy Bolt

1. Fold template along line that is to be folded around door edge.
2. Mark centre of snib hole (A).
3. Mark fixing holes (B, C).
4. Drill 25mm hole for snib turn, as shown on template.
5. Drill 5mm fixing holes (B, C).
6. As per drawing mark centre of door edge, drill 25mm hole.
7. Mark the recess required for the Privacy Bolt face and chisel a 3.5mm recess. Insert Privacy Bolt and secure with screws provided.
8. Fit Striker plate to door jamb so bolt activates through centre of striker plate central opening.

Step 2: Install Privacy Snib Turn Set

1. Insert Spindle through Cam in Privacy bolt. Cut spindle to correct length if necessary.
2. Unscrew mounting brackets from Privacy snib set rosettes.
3. Place mounting brackets over spindle.
4. Mark and drill screw fixing holes that will fix both internal & external side together.
5. Cut fixing screws to length required and fix through both mounting brackets.
6. Screw rosettes back on to mounting brackets on both sides.

