

## Installation instructions

---

The hinge should be mounted as shown.  
The leaves should be positioned on the outside surface of the posts when the gate is closed - see below.

The top edge of the upper hinge should be mounted within 100mm of the top surface of the top rail and the bottom surface of the lower hinge should be mounted within 100mm of the lower surface of the lower rail.

Use screws to fix the legs of the hinge to the sides of the fence and gate post.

